


PARTS FOR: **HVLP SUCTION FEED SPRAY GUN 1.7mm SET-UP** MODEL: HVLP02



1HVLP02.01GUN BODY32HVLP02.32WASHER2HVLP02.02GASKET33HVLP02.33GASKET3HVLP02.03NEEDLE PACKING SPRING34HVLP02.34RETAINER 4mm4HVLP02.04NEEDLE PACKING WASHER35HVLP02.35SPRAY PATTERN ADJUST A5HVLP02.05NEEDLE PACKING GASKET36HVLP02.36SPRAY PATTERN ADJUST L6HVLP02.06NEEDLE PACKING SCREW37HVLP02.37WASHER	EVER (NOB
3HVLP02.03NEEDLE PACKING SPRING34HVLP02.34RETAINER 4mm4HVLP02.04NEEDLE PACKING WASHER35HVLP02.35SPRAY PATTERN ADJUST A5HVLP02.05NEEDLE PACKING GASKET36HVLP02.36SPRAY PATTERN ADJUST L	EVER (NOB
4 HVLP02.04 NEEDLE PACKING WASHER 35 HVLP02.35 SPRAY PATTERN ADJUST A   5 HVLP02.05 NEEDLE PACKING GASKET 36 HVLP02.36 SPRAY PATTERN ADJUST L	EVER (NOB
5 HVLP02.05 NEEDLE PACKING GASKET 36 HVLP02.36 SPRAY PATTERN ADJUST L	EVER (NOB
	NOB
6 HVLP02.06 NEEDLE PACKING SCREW 37 HVLP02.37 WASHER	
7 HVLP02.07 AIR BAFFLE 38 HVLP02.38 SPRAY PATTERN ADJUST K	
8 HVLP02.08 WASHER FOR NOZZLE SEAT 39 HVLP02.39 CROSS HEAD SCREW	•
9 HVLP02.09 NOZZLE SEAT 40 HVLP02.40 NEEDLE ADJUST ADAPTOR	
10 HVLP02.10 NOZZLE 1.7mm 41 HVLP02.41 NEEDLE 1.7mm	
11 HVLP02.11 AIR CAP 1.7mm 42 HVLP02.42 NEEDLE ADJUST SPRING	
12 HVLP02.12 WASHER FOR AIR CAP 43 HVLP02.43 SPRING PLUG	
13 HVLP02.13 LOCKING RING 44 HVLP02.44 NEEDLE ADJUST KNOB	
14 HVLP02.14 RETAINER 45 HVLP02.45 CUP ADAPTER	
15 HVLP02.15 KNOB 46 HVLP02.46 POT	
16 HVLP02.16 SEALING GASKET HVLP02.47 MULTIPURPOSE SPANNER	(not shown)
17 HVLP02.17 SPRING SEAT HVLP02.48 HEX SPANNER (not shown)	
18 HVLP02.18 AIR VALVE SPRING HVLP02.49 BRUSH 'A' (not shown)	
19 HVLP02.19 AIR VALVE SPINDLE HVLP02.50 CLEANING PIN (not shown)	
20 HVLP02.20 AIR VALVE WASHER HVLP02.51 CLEANING PIN (not shown)	
21 HVLP02.21 AIR VALVE HVLP02.52 BRUSH 'B' (not shown)	
22 HVLP02.22 AIR VALVE SEAT HVLP02.53 MALE PLUG (not shown)	
23 HVLP02.23 RETAINER 5mm HVLP02.54 HEX SOCKET (not shown)	
24 HVLP02.24 AIR ADJUST ADAPTER HVLP02-S1.7 SET-UP 1.7mm (not shown)	
25 HVLP02.25 AIR ADJUST KNOB	
26 HVLP02.26 GLAND SEAL OPTIONAL SET-UPS	
27 HVLP02.27 AIR ADAPTER HVLP02-S1.3 SET-UP 1.3mm	
28 HVLP02.28 WASHER HVLP02-S1.4 SET-UP 1.4mm	
29 HVLP02.29 TRIGGER HVLP02-S2.0 SET-UP 2.0mm	
30 HVLP02.30 TRIGGER PIN	
31 HVLP02.31 HINGE PIN	

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. **IMPORTANT:** No liability is accepted for incorrect use of product. **WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode

