



Issue: 1
 Issue Date: 060313

ITEM	PART NO	DESCRIPTION
1	PSI600.01	SOCKET
2	PSI600.02	INDICATOR LIGHT
3	PSI600.03	SWITCH
4	PSI600.04	SCREW FOR PANEL
5	PSI600.05	FRONT PANEL
6	PSI600.06	LOWER PANEL
7	PSI600.07	UPPER PANEL
8	PSI600.08	SIDE COVER
9	PSI600.09	FAN
10	PSI600.10	FAN COVER
11	PSI600.11	SCREW
12	PSI600.12	SCREW
13	PSI600.13	TERMINAL (POSITIVE)
14	PSI600.14	TERMINAL (NEGATIVE)
15	PSI600.15	CIRCUIT BOARD

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.